

## 5: Trouble-shooting

Clicking or popping sounds coming from the Lambda-Nova may be due to pressure on the ear case or by the jerking of your head. Just readjust the headphone on your head to eliminate this trouble.

If the left and the right channel level sound levels seem unbalanced, first check the balance control of the system to be sure that it is set to deliver equal levels to each channel. Then, reverse the input to the adaptor (or direct drive amplifier) so that the left channel input connects to the right channel of the output of the source and the right channel input connects to the left channel of the output source. If the unbalanced phenomenon is reversed, the problem is not the Lambda-Nova. Check the rest of your system. If the unbalanced phenomenon does not reverse, contact your STAX dealer for service.

## 5:トラブルが起きたら

もし、イヤースピーカーからパチパチ音が聞こえたら、振動膜が固定極にタッチしている音かもしれません。これは故障では無い場合がありますので、もうしばらく、様子をご覧ください。(イヤースピーカーを一度強く耳に押しつけると治る場合があります。)

イヤースピーカーの左と右の音量がアンバランスに感じられる(一般にスピーカーよりヘッドフォンの方が左右のアンバランスが目立ちやすい)場合、アンプやアダプターに入力されている信号が左右でアンバランスな場合も考えられます。アンプやアダプターに入力されている信号を左右入れ換えてみて、それでも同じチャンネルがアンバランスな場合はイヤースピーカー・システム(イヤースピーカーとアンプまたはアダプター)に原因がありますから、故障の症状を出来るだけくわしく書いて、お求めになった販売店か、弊社サービス課までお持ちいただくか、お送りください。

(サービス課: ☎:0492-58-3988,

FAX:0492-58-2659)

お送りいただく場合は、お求めいただいた時に入っていた箱に入れ、ひとまわり大きい箱にクッションと共にに入れてお送りください。

